



Vista – Ademco Cheat Sheet

ARM SYSTEM

ARM AWAY:

Make sure all windows and doors are completely closed. With green ready light, type in 4-digit code, then press button number # 2 for *AWAY*.

Red armed light will come on. You have 45 seconds to exit home.

ARM STAY:

Close all windows and doors. With green ready light, type in 4-digit code, then press button # 3 for *STAY* mode.

Red armed light will come on.

The Alarm is on but the motion sensor is off. With the stay setting, if someone opens a window or door that has an alarm sensor the siren will signal instantly. The siren will not go off instantly if someone opens the Delay Zones (entry/exit doors). You will have 30 seconds to punch in the keypad code and *OFF*.

DISARM SYSTEM

DISARM:

To turn off your alarm you must enter 4-digit code, and then press button number # 1 for *OFF*.

Red armed light will go out. System is disarmed. You have 30 seconds to disarm alarm.

BYPASS

BYPASSING ZONES:

To bypass a zone Enter 4-digit code, press button number # 6 for *BYPASS*, and then enter 2-digit zone number of the zone you would like to bypass.

CHIME

TURN CHIME ON OR OFF:

Enter 4-digit code and press button number # 9 for *Chime*.

CHANGING USER CODES

TO CHANGE MASTER CODE:

Enter 4-digit master code, then hit buttons 8 - 0 - 2, then type in the new master code twice.

Keypad will then beep. Note: Do not pause more than 2 seconds while entering commands or it will not work.

TO ADD A USER CODE:

Enter 4-digit master code, then hit 8, then 2-digit user number (03-32), and then type new user code once. Keypad will then beep. Note: Do not pause more than 2 seconds while entering commands or it will not work.

TO ERASE A CODE:

Enter 4-digit master code, then hit 8, then type the 2-digit user number, then hit #, and then hit "0". Keypad will then beep. Note: Do not pause more than 2 seconds while entering commands or it will not work.